


OPERATOR'S MANUAL

KUBOTA FRONT LOADER

MODELS LA513
LA723
LA853



G-6752A

READ AND SAVE THIS MANUAL

Kubota

ABBREVIATION LIST

Abbreviations	Definitions
2WD	Two Wheel Drive
4WD	Four Wheel Drive
API	American Petroleum Institute
ASAE	American Society of Agricultural Engineers, USA
ASTM	American Society for Testing and Materials, USA
DIN	Deutsches Institut für Normung, GERMANY
DT	Dual Traction [4WD]
fpm	Feet Per Minute
GST	Glide Shift Transmission
Hi-Lo	High Speed-Low Speed
HST	Hydrostatic Transmission
m/s	Meters Per Second
PTO	Power Take Off
RH/LH	Right-hand and left-hand sides are determined by facing in the direction of forward travel
ROPS	Roll-Over Protective Structure
rpm	Revolutions Per Minute
r/s	Revolutions Per Second
SAE	Society of Automotive Engineers, USA
SMV	Slow Moving Vehicle
UDT	KUBOTA UDT fluid (Transmission-hydraulic fluid)

FOREWORD

You are now the proud owner of a KUBOTA Loader. This loader is a product of KUBOTA quality engineering and manufacturing. It is made of fine materials and under a rigid quality control system. It will give you long, satisfactory service. To obtain the best use of your loader, please read this manual carefully. It will help you become familiar with the operation of the loader and contains many helpful hints about loader maintenance. It is KUBOTA's policy to utilize as quickly as possible every advance in our research. The immediate use of new techniques in the manufacture of products may cause some small parts of this manual to be outdated. KUBOTA distributors and dealers will have the most up-to-date information. Please do not hesitate to consult with them.



SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use this unit.



DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING : Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

IMPORTANT : Indicates that equipment or property damage could result if instructions are not followed.

NOTE : Gives helpful information.

CONTENTS

SAFE OPERATION	1
SERVICING OF LOADER	1
SPECIFICATIONS	2
SUITABLE TRACTOR	2
LOADER SPECIFICATIONS	2
BUCKET SPECIFICATIONS	3
DIMENSIONAL SPECIFICATIONS	4
OPERATIONAL SPECIFICATIONS	5
LOADER TERMINOLOGY	7
PRE-OPERATION CHECK	8
LUBRICATION	8
TRANSMISSION FLUID	8
TREAD	8
REAR BALLAST	9
Liquid ballast in rear tires	9
TIRE INFLATION	10
Inflation pressure	10
TEST OPERATION	10
REMOVING AIR FROM HYDRAULIC SYSTEM	11
OPERATING THE LOADER	12
FILLING THE BUCKET	12
LIFTING THE LOAD	13
CARRYING THE LOAD	13
DUMPING THE BUCKET	14
LOWERING THE BUCKET	14
OPERATING WITH FLOAT	14
LOADING FROM A BANK	15
PEELING AND SCRAPING	16
LOADING LOW TRUCKS OR SPREADERS FROM A PILE	16
BACKFILLING	17
HANDLING LARGE HEAVY OBJECTS	18
VALVE LOCK	18
Standard valve	18
Remote valve	18
BUCKET LEVEL INDICATOR	19
ATTACHING IMPLEMENTS	19
DETACHING IMPLEMENTS	20
ATTACHMENTS	21
Quick bucket	21
Bale spear	21
Pallet fork	21
ASSEMBLE PALLET FORK	22
MAINTENANCE	23

CONTENTS

LUBRICATION	23
RE-TIGHTENING OF HARDWARE	24
DAILY CHECKS	24
General torque specification	25
REMOVING THE LOADER	26
STORING THE LOADER	28
REINSTALLING THE LOADER	29





SAFE OPERATION

Most loader equipment accidents can be avoided by following simple safety precautions. These safety precautions, if followed at all times, will help you operate your loader safely.

1. Read and understand both the tractor and the loader operator's manuals before using the loader.
Lack of knowledge can lead to accidents.
2. For your safety, ROPS with a seat belt is strongly recommended by KUBOTA in almost all applications. If your tractor has a foldable ROPS, fold it down only when absolutely necessary and fold it up and lock it again as soon as possible. Do not wear the seat belt when the foldable ROPS is down or the fixed ROPS is removed. If you have any questions consult your local KUBOTA Dealer.
Always use seat belt when the tractor is equipped with a ROPS. Never use the seat belt when the tractor is not equipped with a ROPS.
3. Do not lift or carry anybody on the loader, bucket or attachment.
4. Never allow anyone to get under the loader bucket or reach through the boom when the bucket is raised.
5. Do not walk or work under a raised loader bucket or attachment unless it is securely blocked and held in position.
6. Do not use the loader as a Jack to support the tractor for servicing and maintenance.
Securely support tractor or any machine elements with stands or suitable blocking before working underneath.
For your safety, do not work under any hydraulically supported devices. They can settle, suddenly leak down, or be accidentally lowered.
7. When operating on a slope, always operate up and down the slope, never across the slope.
8. Operate the loader from the tractor seat only.
9. For tractor stability and operator's safety, rear ballast must be added to the 3-point hitch and to the rear wheels.
10. To increase stability adjust the rear wheels to the widest setting that is suitable for your application.
11. Move and turn the tractor at low speeds.
12. Carry loader boom at a low position during transport. (You should be able to see over the bucket.)
13. Exercise extra caution when operating the loader with a raised bucket or attachment.
14. Avoid loose fill, rocks and holes. They can be dangerous for loader operation or movement.
15. Be extra careful when working on inclines.
16. Avoid overhead wires and obstacles when loader is raised. Contacting electric lines can cause electrocution.
17. Allow for the loader length when making turns.
18. Gradually stop the loader boom when lowering or lifting.
19. Use caution when handling loose or shiftable loads.
20. When loader work has been completed, lower the loader boom to the ground, stop the engine, remove the key and lock the brakes before leaving the tractor seat.
21. Do not remove loader from tractor without approved bucket attached.
22. Make sure the parked loader is on stands and on a hard, level surface.
23. Operate the loader controls only when properly seated at the controls.
24. Visually check for hydraulic leaks and broken, missing, or malfunctioning parts.
Make necessary repairs before operation.
25. Escaping hydraulic oil under pressure can have sufficient force to penetrate the skin, causing serious personal injury. Do not use hands to search for suspected leaks. If injured by escaping fluid, obtain medical treatment immediately.
26. Before disconnecting hydraulic lines, relieve all hydraulic pressure.
27. Do not tamper with the relief valve setting. The relief valve is pre-set at the factory. Changing the setting can cause overloading of the loader and tractor which may result in a serious personal injury.
28. Using loaders for handling large heavy objects, such as large round or rectangular bales, logs and oil drums is not recommended.
29. Handling large heavy objects can be extremely dangerous due to :
 - Danger of rolling the tractor over.
 - Danger of upending the tractor.
 - Danger of the object rolling or sliding down the loader boom onto the operator.
30. If you must perform this sort of work (item 29), protect yourself by :
 - Never lift the load higher than necessary to clear the ground.
 - Adding rear ballast to the tractor to compensate for the load.
 - Never lift large object with equipment that may permit it to roll back onto the operator.
 - Moving slowly and carefully, avoiding rough terrain.
31. It is the owner's responsibility to be certain anyone operating the loader read this manual first to be aware of the safe way of operating the loader.
32. Always wear safety goggles when servicing or repairing the machine.
33. When servicing or replacing pins in cylinder ends, bucket, etc., always use a brass drift and hammer. Failure to do so could result in injury from flying metal fragments.

- 34. Replace damaged or illegible safety labels. See following page for required labels.
- 35. Do not modify, alter, or permit anyone else to modify or alter the loader, any of its components, or any loader function without first consulting a KUBOTA Dealer.
- 36. Assemble, remove and reinstall the loader only as directed in this manual. Failure to do this could result in serious personal injury or death.
- 37. When operating another implement on a hillside, be sure to remove the loader to reduce the risk of roll over.
- 38. Never lift or pull any load from any point of the loader with a chain, rope, or cable. Doing so could cause a roll over or serious damage to the loader.
- 39. When a front loader is mounted on the tractor, enter and exit the operator's seat only from left side of the tractor.



③ Part No.7J266-5649-1 ④ Part No.7J246-5642-1

⚠ CAUTION

TO AVOID INJURY FROM CRUSHING :

1. Do not utilize the valve lock for machine maintenance or repair.
2. The valve lock is to prevent accidental actuation when loader is not in use or during transport.

⚠ DANGER



TO AVOID SERIOUS INJURY OR DEATH CAUSED BY CONTACT WITH ELECTRIC LINES:

- Check overhead clearance.

① Part No.7J246-5643-1

⚠ DANGER



TO AVOID SERIOUS INJURY OR DEATH CAUSED BY FALLING LOADS :

1. Load on raised bucket or fork can fall or roll back onto operator causing serious injury or death.
2. Use approved clamping and / or guard attachments for handling large, loose or shiftable loads such as bales, posts, sheets of plywood etc.
3. Carry loads as low as possible.

⑤ Part No.7J246-5645-1


⚠ CAUTION

TO AVOID PERSONAL INJURY :

1. Observe safety precautions in loader and tractor Operator's Manual.
2. Operate the loader from tractor seat only.
3. Keep children, others and livestock away when operating loader and tractor.
4. Avoid holes, loose ground, and rocks which may cause tractor / loader to tip.
5. Make sure approved bucket is attached before removing loader from tractor.
6. When parking or storing, choose flat and hard ground. Lower the bucket to the ground, set brakes and remove key before leaving tractor.
7. Before disconnecting hydraulic lines, relieve all hydraulic pressure.

② Part No.7J246-5641-1

⚠ DANGER



TO AVOID SERIOUS INJURY OR DEATH CAUSED BY ROLLOVERS :

1. ROPS and a fastened seat belt are strongly recommended in almost all applications. Foldable ROPS should be in upright and locked position if equipped.
2. Adjust rear wheels to the widest setting that is suitable for the work.
3. Add recommended wheel ballast and rear weight for stability.
4. DO NOT drive on steep slopes or unstable surfaces.
5. Carry loader arms at low position during transport. Move and turn tractor at slow speeds.

⑥ Part No.7J246-5644-2
(Both sides)

⚠ WARNING



TO AVOID INJURY FROM FALLS OR BEING CRUSHED :

1. DO NOT stand or work under raised loader or bucket.
2. DO NOT use loader as jack for servicing.
3. DO NOT use loader as a work platform.
4. NEVER connect chain, cable or rope to loader bucket while operating loader.

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels from your local KUBOTA Dealer.
4. If a component with danger, warning and caution label (s) affixed is replaced with new part, make sure new label (s) is (are) attached in the same location (s) as the replaced component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

SERVICING OF LOADER

Your dealer is interested in your new loader and has the desire to help you get the most value from it. After reading this manual thoroughly, you will find that you can do some of the regular maintenance yourself.


However, when in need of parts or major service, be sure to see your KUBOTA Dealer.

For service, contact the KUBOTA Dealership from which you purchased your loader or your local KUBOTA Dealer.

When in need of parts, be prepared to give your dealer the loader serial number.

Locate the serial numbers now and record them in the space provided.

KUBOTA LOADER
Model
Serial Number
Date of Purchase
Name of Dealer
(To be filled in by purchaser)



(1) Serial number

SPECIFICATIONS

SUITABLE TRACTOR

LA513:L3130,3430

LA723:L3130,3430,3830

LA853:L4330,4630,5030

LOADER SPECIFICATIONS

LOADER MODEL		LA513	LA723	LA853
TRACTOR MODEL		L3130,3430	L3130,3430,3830	L4330,4630,5030
WHEEL BASE(WB)	mm (in)	1805 (71.1)	1805-1840 (71.1-72.4)	1895-1915 (74.6-75.4)
FRONT TIRES		7.2-16	8.3-16	9.5-16
REAR TIRES		12.4-24	14.9-24	14.9-26
BOOM CYLINDER	BORE mm (in)	45(1.77)	50(1.97)	60(2.36)
	STROKE mm (in)	476(18.7)	502(19.8)	496(19.5)
BUCKET CYLINDER	BORE mm (in)	45(1.77)	50(1.97)	55(2.17)
	STROKE mm (in)	476(18.7)	465(18.3)	469(18.5)
CONTROL VALVE		One Detent Float Position, Power Beyond Circuit		
RATED FLOW	L/m (GPM)	31.5(8.3)		37(9.8)
MAXIMUM PRESSURE	MPa (kg/cm ² ,psi)	185(2630)		
NET WEIGHT(APPROXIMATE)	kg (lbs.)	390(860)	480(1058)	525(1157)

BUCKET SPECIFICATIONS

LOADER MODEL		LA513		LA723		LA853	
MODEL		SQUARE 66"	ROUND 66" HD	SQUARE 72"	ROUND 72" HD	SQUARE 72"	ROUND 72" HD
TYPE		RIGID	RIGID	RIGID	RIGID	RIGID	RIGID
WIDTH	mm (in.)	1675 (66)		1830 (72)			
DEPTH (L)	mm (in.)	458 (18)	440 (17.3)	509 (20)	440 (17.3)	547 (21.5)	477 (18.8)
HEIGHT (M)	mm (in.)	562 (22.1)	580 (22.8)	562 (22.1)	580 (22.8)	570 (22.4)	608 (23.9)
LENGTH (N)	mm (in.)	502 (19.8)	531 (20.9)	591 (23.3)	570 (22.4)	652 (25.7)	630 (24.8)
CAPACITY	STRUCK m ³ (CU.FT.)	0.23 (8.1)		0.25 (8.8)		0.31 (10.9)	
	HEAPED m ³ (CU.FT.)	0.28 (9.9)		0.31 (10.9)		0.37 (13.1)	
WEIGHT	kg (lbs.)	112 (247)	122 (269)	133 (293)	150 (331)	146(322)	164 (362)


LOADER MODEL		LA513,LA723,LA853		LA723,LA853		LA513,LA723,LA853
MODEL		SQUARE 66"	ROUND 66" HD	SQUARE 72"	ROUND 72" HD	SQUARE 72" LIGHT MATERIAL
TYPE		QUICK ATTACH	QUICK ATTACH	QUICK ATTACH	QUICK ATTACH	QUICK ATTACH
WIDTH	mm (in.)	1675 (66)		1830 (72)		
DEPTH (L)	mm (in.)	458 (18)	440 (17.3)	547 (21.5)	477 (18.8)	607 (23.9)
HEIGHT (M)	mm (in.)	562 (22.1)	580 (22.8)	570 (22.4)	608 (23.9)	570 (22.4)
LENGTH (N)	mm (in.)	544 (21.4)	570 (22.4)	630 (24.8)	610 (24)	691 (27.2)
CAPACITY	STRUCK m ³ (CU.FT.)	0.23 (8.1)		0.31 (10.9)		0.36 (12.7)
	HEAPED m ³ (CU.FT.)	0.28 (9.9)		0.37 (13.1)		0.45 (16.0)
WEIGHT	kg (lbs.)	120 (265)	130 (287)	150 (331)	180 (397)	136 (300)

DIMENSIONAL SPECIFICATIONS



	LOADER MODEL		LA513	LA723	LA853
	TRACTOR MODEL		L3130,3430	L3130,3430,3830	L4330,4630,5030
A	MAX. LIFT HEIGHT (TO BUCKET PIVOT PIN)	mm (in.)	2450 (96.5)	2600 (102.4)	2885 (113.6)
B	MAX. LIFT HEIGHT UNDER LEVEL BUCKET	mm (in.)	2280 (89.8)	2400 (94.5)	2685 (105.7)
C	CLEARANCE WITH BUCKET DUMPED	mm (in.)	1995 (78.5)	2040 (80.3)	2280 (89.8)
D	REACH AT MAX. LIFT HEIGHT (DUMPING REACH)	mm (in.)	525 (20.7)	530(20.9)	510 (20.1)
E	MAX. DUMP ANGLE	deg.	40	45	
F	REACH WITH BUCKET ON GROUND	mm (in.)	1570 (61.8)	1750 (68.9)	1905 (75)
G	BUCKET ROLL-BACK ANGLE	deg.	30	40	
H	DIGGING DEPTH	mm (in.)	125 (4.9)		170 (6.7)
J	OVERALL HEIGHT IN CARRYING POSITION	mm (in.)	1335 (52.6)	1385 (54.5)	1450 (57.1)

OPERATIONAL SPECIFICATIONS



	LOADER MODEL		LA513	LA723	LA853
	TRACTOR MODEL		L3130,3430	L3130,3430, 3830	L4330,4630, 5030
	LIFT CAPACITY (BUCKET BOTTOM MID POINT)	kg (lbs.)	510 (1124)	720 (1587)	850 (1874)
U	LIFT CAPACITY (BUCKET PIVOT PIN, MAX. HEIGHT)	kg (lbs.)	610 (1345)	848 (1870)	1077 (2374)
V	LIFT CAPACITY (500mm FORWARD, MAX. HEIGHT)	kg (lbs.)	455 (1003)	635 (1400)	800 (1764)
W	LIFT CAPACITY (BUCKET PIVOT PIN, 1500mm HEIGHT)	kg (lbs.)	800 (1764)	1051 (2317)	1345 (2965)
X	LIFT CAPACITY (500mm FORWARD, 1500mm HEIGHT)	kg (lbs.)	630 (1389)	840 (1852)	1086 (2394)
Y	BREAKOUT FORCE (BUCKET PIVOT PIN)	N (lbs.)	12640 (2845)	14995 (3375)	17840 (4015)
Z	BREAKOUT FORCE (500mm FORWARD)	N (lbs.)	9600 (2160)	11575 (2605)	13880 (3125)
VV	BUCKET ROLL-BACK FORCE AT MAX. HEIGHT	N (lbs.)	10650 (2395)	10330 (2325)	10910 (2455)
XX	BUCKET ROLL-BACK FORCE AT 1.5M	N (lbs.)	13780 (3100)	15520 (3490)	18640 (4190)
ZZ	BUCKET ROLL-BACK FORCE AT GROUND LEVEL	N (lbs.)	11880 (2670)	16090 (3620)	19750 (4440)
	RAISING TIME	sec.	2.7	3.3	4.1
	LOWERING TIME	sec.	2.2	2.2	3.1
	BUCKET DUMPING TIME	sec.	1.3	1.3	1.6
	BUCKET ROLLBACK TIME	sec.	1.6	2.1	2.2





LA513




LA723



LA853



LOADER TERMINOLOGY





- (1) Hydraulic control valve
- (2) Side frame
- (3) Mounting pin
- (4) Main frame
- (5) Boom cylinder

- (6) Boom
- (7) Bucket cylinder
- (8) Bucket

PRE-OPERATION CHECK

LUBRICATION

Lubricate all grease fittings with SAE multipurpose grease.



TRANSMISSION FLUID

Check tractor transmission fluid level. Add fluid if necessary. Refer to the tractor operator's manual for instructions and proper fluid. Repeat this check after purging air from the system. At that time, it will be necessary to add transmission fluid.

IMPORTANT :

- To check tractor transmission fluid level, lower the bucket to the ground and lower the 3 point hitch.

TREAD

1. Set front tread as follows.

	Front Tread	
	2WD	4WD
L3130 L3830	1310mm (51.6 in)	Front axle is not adjustable.

IMPORTANT :

- Setting tread wider than recommended may cause premature failure of front axle components due to excessive stress.

2. For better stability, set the rear tread as follows depending on the requirements of the work being done.

	Rear Tread
L3130 L3430	1200mm (47.2 in.) or more
L3830 L4330 L4630	1285mm (50.6 in.) or more
L5030	1325mm (52.2 in.) or more

REAR BALLAST



CAUTION

To avoid personal injury:

- For tractor stability and operator's safety, rear ballast should be added to the rear of the tractor in the form of 3-point counter weight and rear wheel ballast. The amount of rear ballast will depend on the application.

Implement as Counter Weight	
6' Box Scraper	Approx. 450 kg (990 lbs.)
Rotary Tiller	Approx. 240 kg (530 lbs.)
Back Hoe	Approx. 770 kg (1690 lbs.)

■ Liquid ballast in rear tires

Water and calcium chloride solution provides a safe and economical ballast. Used properly, it will not damage tires, tubes or rims. The addition of calcium chloride is recommended to prevent the water from freezing. Use of this method of weighting the wheels has full approval of the tire manufacturers. See your tire dealer for this service.


Liquid weight per tire (75 Percent filled)

Tire sizes	12.4-24	420/70-24	14.9-24
Slush free at -10 °C (14 °F) Solid at -30 °C (-22 °F) [Approx. 1 kg (2 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	130 kg (285 lbs.)	195 kg (430 lbs.)	205 kg (450 lbs.)
Slush free at -24 °C (-11 °F) Solid at -47 °C (-52 °F) [Approx. 1.5 kg (3.5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	135 kg (295 lbs.)	205 kg (450 lbs.)	215 kg (475 lbs.)
Slush free at -47 °C (-52 °F) Solid at -52 °C (-62 °F) [Approx. 2.25 kg (5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	145 kg (320 lbs.)	220 kg (485 lbs.)	225 kg (495 lbs.)

Tire sizes	17.5L-24	14.9-26	13.6-28
Slush free at -10 °C (14 °F) Solid at -30 °C (-22 °F) [Approx. 1 kg (2 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	235 kg (515 lbs.)	215 kg (475 lbs.)	185 kg (405 lbs.)
Slush free at -24 °C (-11 °F) Solid at -47 °C (-52 °F) [Approx. 1.5 kg (3.5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	250 kg (550 lbs.)	225 kg (495 lbs.)	200 kg (441 lbs.)
Slush free at -47 °C (-52 °F) Solid at -52 °C (-62 °F) [Approx. 2.25 kg (5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	265 kg (585 lbs.)	235 kg (515 lbs.)	215 kg (475 lbs.)

IMPORTANT :

- Do not fill tires with water or solution more than 75% of full capacity (to the valve stem level at 12 o'clock position).
- Do not fill tires with water or solution if the tractor is a CAB model.



F-7749A

(1) Air

(A) Correct: 75% Full

Air compresses like a cushion

(2) Water

(B) Incorrect: 100% Full

Water can not be compressed

NOTE :

- When mounting a heavy rear implement, liquid in the tires may not be required.

IMPORTANT :

- Do not add liquid ballast or any other weights to the front tires.

TIRE INFLATION

Insure that the tractor tires are properly inflated.
Refer to the tractor operator's manual for optional tires.

■ Inflation pressure

	Tire sizes	Inflation Pressure
Rear	12.4-24, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	13.6-28, 4PR	150 kPa (1.5 kgf/cm ² , 22 psi)
	14.9-24, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	14.9-26, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	41/18LL x 16.1, 6PR	70 kPa (0.7 kgf/cm ² , 10 psi)
	355/80-D20, 4PR	100 kPa (1.0 kgf/cm ² , 14 psi)
	44 x 18-20, 6PR	170 kPa (1.7 kgf/cm ² , 24 psi)
	420/70-24, 6PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	17.5L-24, 6PR	140 kPa (1.4 kgf/cm ² , 20 psi)
Front	6.00-16, 4PR	220 kPa (2.2 kgf/cm ² , 32 psi)
	7.2-16, 4PR	150 kPa (1.5 kgf/cm ² , 22 psi)
	8.3-16, 4PR	150 kPa (1.5 kgf/cm ² , 22 psi)
	9.5-16, 4PR	205 kPa (2.1 kgf/cm ² , 30 psi)
	27 x 8.50-15, 4PR	85 kPa (8.5 kgf/cm ² , 12 psi)
	27 x 10.50-15, 4PR	85 kPa (8.5 kgf/cm ² , 12 psi)
	29 x 12.50-15, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	10-16.5, 6PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	7.5L-15, 6PR	220 kPa (2.2 kgf/cm ² , 32 psi)

TEST OPERATION



CAUTION

To avoid serious personal injury:

- Keep engine speed at low idle during the test operation.


- Escaping hydraulic fluid under pressure can have sufficient force to penetrate skin, causing serious personal injury.

Before disconnecting lines, be sure to relieve all pressure.

Before applying pressure to system, be sure all connections are tight and that lines, tubes and hoses are not damaged.

Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than your hands to search for suspected leaks.

If injured by escaping fluid, see a doctor at once. Serious infection or allergic reaction will develop if proper medical treatment is not administered immediately.



NOTE :

- When the lever is at each corner position marked by asterisk (*), boom and bucket cylinders work at the same time. However, the position marked is not recommended for scooping because of insufficient lift force.

To begin test operation, slightly move the control lever from the "N" position. Slowly raise the loader boom just enough for the bucket to clear the ground when fully dumped. Slowly work through the dump and roll back cycles.

IMPORTANT :

- If the boom or bucket does not work in the directions indicated on the label, lower the bucket to the ground, stop the engine, and relieve all hydraulic pressure. Recheck and correct all hydraulic connections.

REMOVING AIR FROM HYDRAULIC SYSTEM

Repeat raising and lowering the boom and bucket operations until all the air is removed from the system and the system responds properly.

IMPORTANT :

- Do not move the control lever into float position when the bucket is off the ground.

OPERATING THE LOADER

The loader should be operated with the tractor engine speed depending on the application and the operator's level of experience. Excessive speeds are dangerous, and may cause bucket spillage and unnecessary strain on the tractor and loader.

When operating in temperatures below -1°C (30°F), run the tractor engine below 1200 rpm until the oil temperature exceeds -1°C (30°F).

The following text and illustrations offer suggested loader and tractor operating techniques.



CAUTION

To reduce the possibility of roll over:


- It is not recommended that the loader be attached when operating another implement on a hillside.

IMPORTANT:


- When operating the loader in rough terrain, remove the mower to avoid damage to the mower.

FILLING THE BUCKET


Approach and enter the pile with a level bucket.



Ease control lever toward you and then back to rollback and lift the bucket.



The rollback and lifting of the bucket will increase efficiency because a level bucket throughout the lifting cycle resists bucket lift and increases breakaway effort.




NOTE:

- Do not be concerned if the bucket is not completely filled during each pass. Maximum productivity is determined by the amount of material loaded in a given period of time. Time is lost if two or more attempts are made to fill the bucket on each pass.

LIFTING THE LOAD

When lifting the load, keep the bucket positioned to avoid spillage.




WARNING

To avoid serious personal injury:

- Do not attempt to lift bucket loads in excess of the loader capacity.
- Before raising the bucket to full height, make sure the tractor is on level ground. If not, it may tip over, even if the tractor is not moving.

CARRYING THE LOAD

Position the bucket just below the level of the tractor hood for maximum stability and visibility, whether the bucket is loaded or empty.




Use extreme care when operating the loader on a slope. Keep the bucket as low as possible. This keeps the bucket and tractor center of gravity low and will provide maximum tractor stability.



WARNING

To avoid serious personal injury:

- Be extra careful when working on inclines.
- When operating on a slope, always operate up and down the slope, never across the slope.




When transporting a load, keep the bucket as low as possible to avoid tipping, in case a wheel drops in a rut.




DUMPING THE BUCKET

Lift the bucket just high enough to clear the side of the vehicle. Move the tractor in as close to the side of the vehicle as possible, then dump the bucket.



LOWERING THE BUCKET


After the bucket is dumped, back away from the vehicle while lowering and rolling back the bucket.




OPERATING WITH FLOAT

During operation on hard surface, keep the bucket level and put the lift control in the float position to permit the bucket to float on the working surface.

If hydraulic down pressure is exerted on the bucket it will wear faster than normal.




The float position will also avoid mixing of surface material with stockpile material. The float position will reduce the chance of surface gouging while removing snow or other material, or when working with a blade.




LOADING FROM A BANK

Choose a forward gear that provides a safe ground speed and power for loading.



It is important to keep the bucket level when approaching a bank or pile. This will help avoid gouging the work area.



WARNING


To avoid serious personal injury:

- Be extra careful when working on inclines.
- When operating on a slope, always operate up and down the slope, never across the slope.


NOTE :

- Loader lift and break-away capacity diminish as loading height is increased.


Side cutting is a good technique for cutting down a big pile. Wheel width should not exceed the bucket width for this procedure.



If the pile sides are too high and liable to cause cave-in, use the loader to break down the sides until a slot can be cut over the top.




Another method for large dirt piles is to build a ramp to approach to the pile.




PEELING AND SCRAPING


Use a slight bucket down angle, travel forward, and hold the lift control forward to start the cut. Make a short cut and break-out cleanly.



With the bucket level, start a cut at the notch approximately 2 in. deep. Hold the depth by feathering the bucket control to adjust the cutting edge up or down. When the front tires enter the notch, adjust the boom cylinder to maintain proper depth.




Make additional passes until the desired depth is reached. During each pass, use only the bucket control while at working depth. This will allow you to concentrate on controlling the bucket angle to maintain a precise cut.




LOADING LOW TRUCKS OR SPREADERS FROM A PILE

For faster loading, minimize the angle of turn and length of run between pile and spreader.




Backgrade occasionally with a loaded bucket to keep the work surface free of ruts and holes. Also, hold the lift control forward so the full weight of the bucket is scraping the ground. Use the heel of the bucket




BACKFILLING

Approach the pile with the bucket flat.




Poor operating methods will move less dirt and make it more difficult to hold a level grade.




IMPORTANT :

- Do not use the bucket in the dumped position for bulldozing. As shown above, this method will impose severe shock loads on the dump-linkage, the bucket cylinders, and the tractor.


Leave dirt in the bucket because dumping on each pass wastes time.




Operate at right angles to the ditch. Taking as big a bite as the tractor can handle.



Leave dirt which drifts over the side of the bucket for final cleanup.



Pile dirt on the high side for easier backfilling on a slope.



HANDLING LARGE HEAVY OBJECTS



DANGER

To avoid serious personal injury or death:


- Handling large, heavy objects can be dangerous due to :
 - (A) Danger of rolling the tractor over.
 - (B) Danger of upending the tractor.
 - (C) Danger of the object rolling or sliding down the loader boom onto the operator.
- If you must perform the above work, protect yourself by :
 - (A) Not lifting the load higher than necessary to clear the ground when moving.
 - (B) Adding rear ballast to the tractor to compensate for the load.
 - (C) Not lifting large objects with equipment that does not have an anti-rollback device.
 - (D) Moving slowly and carefully.
 - (E) Avoiding rough terrain.
 - (F) Keeping transport distance as short as possible and carry the load as low as possible during transport.

VALVE LOCK

The control valve is equipped with a valve lock feature. The control valve is locked in the neutral position. The purpose of the control valve lock is to prevent the accidental activation when the loader is not in use or during transport.

The lock is not intended to and will not prevent leak down of the loader boom during storage.


■ Standard valve



(1) Lock lever

(A) "Lock"
(B) "Unlock"

■ Remote valve




(1) Lock lever

(A) "Lock"
(B) "Unlock"

BUCKET LEVEL INDICATOR

The length of the level indicator rod is intentionally provided longer than necessary.

The rod may be cut to meet the operator's preference.




(1) Indicator rod

ATTACHING IMPLEMENTS

NOTE :


- Implements should be located on a flat, firm surface when attaching and detaching them from the L2230, L2231, L2232 Quick Hitch.

1. To mount an implement, pull the handles of the quick hitch latching pins to the unlatched position. The quick hitch handles must be all the way up to ensure that the latching pins are fully retracted.
2. Position the tractor squarely in front of the implement and tilt the quick hitch forward with the bucket cylinders.



(1) Quick hitch

3. Ease the quick hitch mounting plate into the saddle of the implement.
4. Without raising the implement from the ground, roll the quick hitch back using the bucket cylinders and raise the boom slightly. The back of the implement should rest flat against the front of the quick hitch mounting plate and the weight of the implement should be supported by the loader.




(1) Quick hitch

**CAUTION**

TO AVOID PERSONAL INJURY OR MACHINE DAMAGE:

- DO NOT RAISE IMPLEMENT COMPLETELY OFF THE GROUND AT THIS POINT. THE IMPLEMENT COULD SWING OFF THE QUICK HITCH.

5. When the implement is properly seated in the saddle and against the front of the quick hitch mounting plate, turn off the engine and set the parking brake. Push the quick hitch handles to the fully latched position. Verify both latching pins are completely engaged in the base of the implement.



(1) Quick hitch handle

6. You are now ready to use the attached implement. All compatible implements attach and detach using the same method.

**CAUTION**

TO AVOID PERSONAL INJURY OR MACHINE DAMAGE:


- NEVER OPERATE OR TRANSPORT IMPLEMENTS WHICH ARE NOT ATTACHED COMPLETELY.
- ALWAYS REPLACE DAMAGED HARDWARE IMMEDIATELY.

DETACHING IMPLEMENTS

1. Detaching implements is done in the reverse of attaching implements. The procedure is below.
2. Lower the implement to ground level with the implement slightly in the rolled back position. Stop the engine and set the parking brake.
3. Pull the quick hitch handles to the unlatched position to release the latching pins.
4. While sitting in the tractor operator's seat, start the engine and slowly move the loader control lever to the "DUMP" position until the implement is pushed away slightly from the Quick Hitch.
5. Lower the loader boom so that the quick hitch mounting plate clears the implement saddle.
6. Back away from the implement slowly.
7. If an implement is not going to be attached to the quick hitch immediately, push the handles of the quick attach to the locked position to prevent damage to the handle assembly.


ATTACHMENTS

■ Quick bucket




- SQUARE 66"
 - WIDTH
 - 1675mm (66in.)
 - STRUCK CAPACITY
 - 0.23 cu.m. (8.1cu.ft.)
 - APPLICABLE LOADER MODEL
 - LA513,LA723,LA853
- ROUND 66" HD
 - WIDTH
 - 1675mm (66in.)
 - STRUCK CAPACITY
 - 0.23 cu.m. (8.1cu.ft.)
 - APPLICABLE LOADER MODEL
 - LA513,LA723,LA853
- SQUARE 72"
 - WIDTH
 - 1830mm (72in.)
 - STRUCK CAPACITY
 - 0.31cu.m. (10.9cu.ft.)
 - APPLICABLE LOADER MODEL
 - LA723,LA853
- ROUND 72"HD
 - WIDTH
 - 1830mm (72in.)
 - 0.31cu.m. (10.9cu.ft.)
 - STRUCK CAPACITY
 - APPLICABLE LOADER MODEL
 - LA723,LA853
- SQUARE 72" LIGHT MATERIAL
 - WIDTH
 - 1830mm (72in.)
 - STRUCK CAPACITY
 - 0.36cu.m. (12.7cu.ft)
 - APPLICABLE LOADER MODEL
 - LA513,LA723,LA853

■ Bale spear



- OVERALL HEIGHT
- 524mm (20.63in.)
- OVERALL WIDTH
- 1149mm (45.24in.)
- OVERALL LENGTH (INCLUDING MAIN SPEAR)
- 1376mm (54.17in.)
- USEABLE LENGTH OF MAIN SPEAR
- 1008mm (39.69in.)
- USEABLE LENGTH OF SPEAR 2
- 356mm (14.02in.)
- MAXIMUM DIAMETER OF MAIN SPEAR
- 51mm (2.00in.)
- DIAMETER OF SPEAR 2
- 32mm (1 1/4in.)
- WEIGHT OF IMPLEMENT
- 74kg (163lbs)


■ Pallet fork



LOADER MODEL	RATED CAPACITY
LA513	800LBS.
LA723	1000 LBS.
LA853	1300 LBS.


ASSEMBLE PALLET FORK

1. Install the fork to the middle of the frame.
(fit the lower hook of the fork to the center notch of the frame)




(1) Fork

2. Slide the fork to the desired position.




(1) Fork

3. Push the lock lever and slide the fork slightly until the lock pin engages with one of the notches to lock the fork.



(1) Lock lever

4. The other fork can be installed by the same procedures.



MAINTENANCE





CAUTION

To avoid personal injury:

- Be sure to check and service the tractor on a flat place with the bucket on the ground, engine shut off, the key removed and the parking brake on.

LUBRICATION

1. Lubricate all grease fittings every 10 hours of operation. Also, lubricate joints of control lever linkage every 10 hours. High quality grease designating "extreme pressure" and containing Molybdenum disulfide is recommended. This grease may specify "Moly EP" on its label.



2. Daily before operation, check the tractor hydraulic fluid level. If low, add as described in the tractor's operator's manual. Also change the filter element and the hydraulic fluid as recommended in the tractor's operator's manual.

RE-TIGHTENING OF HARDWARE

After 20 to 30 hours of initial loader operation, re-tighten all mounting bolts and nuts to the required torque value as follows.

Sequence	Location	Bolt/Nut	Required Torque kgf-m (ft-lbs)
1	Main frames (Front axle frame)	M16 bolts	23 (166)
2	Main frames (Rear brackets)	M16 nuts	23 (166)

DAILY CHECKS


1. Check all hardware daily before operation. Tighten hardware to torque values as specified in the "Installation Instructions" and "Tightening Torque Chart".
2. With the engine off and the bucket on the ground, inspect all hoses for cuts or wear. Check for signs of leaks and make sure all fittings are tight.



WARNING

To avoid serious personal injury:

- Escaping hydraulic fluid under pressure can have sufficient force to penetrate skin, causing serious personal injury. Before disconnecting lines, be sure to relieve all pressure. Before applying pressure to system, be sure all connections are tight and that lines, tubes, and hoses are not damaged. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than your hands, to search for suspected leaks. Use a magnifying glass to inspect for small leaks.



- (1) Hydraulic line
(2) Cardboard
(3) Magnifying glass


If injured by escaping fluid, see a doctor at once. Serious infection or allergic reaction will develop if proper medical treatment is not administered immediately.

- When removing the engine side covers, be careful not to touch hot loader cylinders. Allow all surfaces to cool before performing maintenance.

General torque specification

American standard screws, bolts and nuts with UNC or UNF threads				Metric cap screws 		
SAE grade No.		SAE GR.5 	SAE GR.8 	property class		8.8 Approx. SAE GR 5
1/4	(N-m) (kgf-m) (ft-lbs)	11.7 to 15.8 1.19 to 1.60 8.6 to 11.6	16.3 to 19.8 1.66 to 2.02 12.0 to 14.6	M6	(N-m) (kgf-m) (ft-lbs)	9.8 to 11.2 1.0 to 1.1 7.2 to 8.3
5/16	(N-m) (kgf-m) (ft-lbs)	23.1 to 27.8 2.35 to 2.84 17.0 to 20.5	32.5 to 39.3 3.31 to 4.01 24.0 to 29.0	M8	(N-m) (kgf-m) (ft-lbs)	23.6 to 27.4 2.4 to 2.8 17.4 to 20.2
3/8	(N-m) (kgf-m) (ft-lbs)	47.5 to 57.0 4.84 to 5.82 35.0 to 42.0	61.0 to 73.2 6.22 to 7.47 45.0 to 54.0	M10	(N-m) (kgf-m) (ft-lbs)	48.1 to 55.8 4.9 to 5.7 35.5 to 41.2
1/2	(N-m) (kgf-m) (ft-lbs)	108.5 to 130.2 11.07 to 13.29 80.0 to 96.0	149.2 to 179.0 15.22 to 18.27 110.0 to 132.0	M12	(N-m) (kgf-m) (ft-lbs)	77.5 to 90.1 7.9 to 9.2 57.2 to 66.5
9/16	(N-m) (kgf-m) (ft-lbs)	149.2 to 179.0 15.22 to 18.27 110.0 to 132.0	217.0 to 260.4 22.14 to 26.57 160.0 to 192.0	M14	(N-m) (kgf-m) (ft-lbs)	124 to 147 12.6 to 15.0 91.2 to 108
5/8	(N-m) (kgf-m) (ft-lbs)	203.4 to 244.1 20.75 to 24.91 150.0 to 180.0	298.3 to 358.0 30.44 to 36.53 220.0 to 264.0	M16	(N-m) (kgf-m) (ft-lbs)	196 to 225 20.0 to 23.0 145 to 166

Top of bolt



M6

M8


M10

M12

M14

M16

Length



REMOVING THE LOADER




CAUTION

To avoid personal injury:


- Make sure approved bucket is attached before removing loader from tractor.
- For removing the loader, choose flat and hard ground, preferably concrete.
- If the ground surface is soft, place suitable planks on the ground for the bucket and stands.
- When starting the engine or using the hydraulic control valve, always sit in the operator's seat.
- Make sure bucket and stands are at ground level.

1. Raise the boom until the stands can be rotated.
2. Stop the engine.
3. Remove the spring pins holding the stands to the boom.
4. Rotate the stands until the pin on the stand and hole in the boom are aligned.
Then slide the stands outward and insert the spring pin as shown.



(1) Stand
(2) Spring pin

5. Start the engine and run at idle.
6. Dump the bucket approximately 20 degrees.
7. Lower the boom and raise the front wheels slightly.




(1) Stand

IMPORTANT :


- Lift the weight off the front wheels with the bucket. Do not attempt to lift them with the stands.

8. Stop the engine.
9. Remove the mounting pins from the loader main frame and hold them on boom.
10. Start the engine and run at idle. Slowly move the hydraulic control lever to rollback position to raise the loader side frames up and out of the receivers of the main frames as shown.



(1) Hydraulic control lever

11. Stop the engine.
12. Slowly release all hydraulic pressure by moving the hydraulic control lever in all directions.
13. Disconnect the four hoses with quick couplers at the control valve and place them on the right side of the boom.
14. Place the protective caps and plugs on the quick coupler ends.




(1) Protective plug

15. Start the engine and slowly back the tractor away from the loader.

STORING THE LOADER

1. Store the loader in a clean dry place.
2. Make sure the loader is properly supported.
3. Attach the protective plugs and caps to the couplers to protect from dust.



4. Check hydraulic hoses and connections. Repair or replace if necessary.
5. Repair or replace any worn, damaged or missing parts.
6. Lubricate loader as described "LUBRICATION" in Maintenance section.
7. Apply a coat of grease to all exposed cylinder rods and mounting pins to prevent rust.
8. Repaint worn or scratched parts.

REINSTALLING THE LOADER




CAUTION

To avoid personal injury:


- When starting the engine and operating the control valve, always sit in the operator's seat.

1. Slowly drive the tractor between the loader side frames until the rear portion of both side frames touches the main frames as shown.



(1) Side frame
(2) Main frame


2. Stop the engine.
3. Connect four hoses with couplers to the nipples on the control valve as indicated with color marks. Then connect the protective caps and plugs to each other.



(1) Hoses

4. Start the engine and run at idle.

5. Slowly move the hydraulic control lever to dump position to lower the side frames into the main frames and engage the bosses of the side frames to the guide plates of the main frames. Then lift the weight off the front wheels with the loader - do not lift the wheels off the ground.




(1) Hydraulic control lever

IMPORTANT :

- Do not attempt to lift the front wheels with the stands.

6. Stop the engine. Reinstall the mounting pins and secure them with the spring pins.
7. Start the engine.
8. Raise the boom until the stands can be rotated.
9. Stop the engine.
10. Store the stands to their original positions and secure them with the spring pins as shown.



(1) Stand
(2) Spring pin

11. Start the engine.
12. Lower the boom and level the bucket.

KUBOTA Corporation is . . .

Since its inception in 1890, KUBOTA Corporation has grown to rank as one of the major firms in Japan.

To achieve this status, the company has through the years diversified the range of its products and services to a remarkable extent. Nineteen plants and 16,000 employees produce over 1,000 different items, large and small.

All these products and all the services which accompany them, however, are unified by one central commitment. KUBOTA makes products which, taken on a national scale, are basic necessities. Products which are indispensable. Products which are intended to help individuals and nations fulfill the potential inherent in their environment. KUBOTA is the Basic Necessities Giant.

This potential includes water supply, food from the soil and from the sea, industrial development, architecture and construction, and transportation.

Thousands of people depend on KUBOTA's know-how, technology, experience and customer service. You too can depend on KUBOTA.



- U.S.A. : **KUBOTA TRACTOR CORPORATION**
3401 Del Amo Blvd., Torrance, CA 90503, U.S.A.
Telephone : (310)370-3370
- Western Division : 6665 E. Hardaway Rd., Stockton, CA 95215
Telephone : (209)931-5051
- Central Division : 14855 FAA Blvd., Fort Worth, TX 76155
Telephone : (817)571-0900
- Northern Division : 2626 Port Road, Columbus, OH 43217
Telephone : (614)492-1100
- Southeast Division : 1025 Northbrook Parkway, Suwanee, GA 30024
Telephone : (770)995-8855
- Canada : **KUBOTA CANADA LTD.**
5900 14th Avenue, Markham, Ontario, L3S 4K4, Canada
Telephone : (905)294-7477
- Delta Distribution Center : 7979 82nd St, Delta B.C. V4G 1L7
Telephone : (604)940-6061
- Drummondville Distribution Center : 5705 Place Kubota, Drummondville, Québec, J2B 6B4
Telephone : (819)478-7151
- France : **KUBOTA EUROPE S.A.**
19-25, Rue Jules Vercey, Z.I. BP88, 95101 Argenteuil Cedex, France
Telephone : (33)1-3426-3434
- Germany : **KUBOTA (DEUTSCHLAND) GmbH**
Senefelder Str. 3-5 63110 Rodgau /Nieder-Roden, Germany
Telephone : (49)6106-873-0
- U.K. : **KUBOTA (U.K.) LTD.**
Dormer Road, Thame, Oxfordshire, OX9 3UN, U.K.
Telephone : (44)1844-214500
- Australia : **KUBOTA TRACTOR AUSTRALIA PTY LTD.**
100 Keilor Park Drive, Tullamarine, Victoria 3043 Australia
Telephone : (61)-3-9279-2000
- Malaysia : **SIME KUBOTA SDN. BHD.**
Lot pt 11101 Kompleks Sime Darby, Jalan Kewajipan,
Subang Jaya, 47600 Petaling Jaya, Selangor Darul Ehsan, West Malaysia
Telephone : (60)3-736-1388
- Philippines : **KUBOTA AGRO-INDUSTRIAL MACHINERY PHILIPPINES, INC.**
155 Panay Avenue, South Triangle Homes, 1103 Quezon City, Philippines
Telephone : (63)2-9201071
- Taiwan : **SHIN TAIWAN AGRICULTURAL MACHINERY CO., LTD.**
16, Fengping 2nd Rd, Taliiao Shiang Kaohsiung 83107, Taiwan R.O.C.
Telephone : (886)7-702-2333
- Brazil : **KUBOTA BRASIL LTDA.**
Rua Dona Maria Fidelis No.171, Diadema, São Paulo, Brazil
Telephone : (55)11-745-4744
- Indonesia : **P.T. KUBOTA INDONESIA**
JALAN. Setyabudi 279, Semarang, Indonesia
Telephone : (62)-24-472849
- Thailand : **THE SIAM KUBOTA INDUSTRY CO., LTD.**
101/19-24 Navanakorn, Tambol Klongneung, Amphur Klongluang, Pathumtani 12120, Thailand
Telephone : (66)2-529-0363
- Egypt : **KUBOTA Corporation CAIRO LIAISON OFFICE**
Flat No.2,27th floor, Swiss Tower Building
3,Ibn Kasir Street, Cornish EL Nile, Giza, Egypt
Telephone : (20)2-338-3851

KUBOTA Corporation

Code No. 7J266-6911-2